

QUICK START GUIDE

Slatted Pool Cover



BEFORE YOU OPERATE

- ✓ Pool water level at middle of skimmer
- ✓ No people, pets or objects in pool
- ✓ Cover path clear of debris

HOW TO OPERATE

- Always watch the cover while moving
- Cover must move smoothly and evenly
- Stop immediately if it catches, lifts, jams or sounds strained

STOP IMMEDIATELY IF:

- ⊘ Cover looks uneven or twisted
- ⊘ Slats lift or catch
- ⊘ Cover does not open or close correctly

DO NOT:

- ⊘ Operate with low or high water level
- ⊘ Force the cover
- ⊘ Allow children to operate
- ⊘ Leave cover partially open

IMPORTANT WARRANTY NOTICE

Damage caused by incorrect water level, misuse, forcing the cover or failure to visually monitor operation is not covered by warranty.

NEED HELP?

Stop using the cover and contact Daisy Pool Covers immediately.

1300 55 18 11 | hello@daisypoolcovers.com.au

INSTALL INFORMATION

INSTALLED BY

SYSTEM TYPE

POOL OWNER

INSTALLATION DATE

1. IMPORTANT – READ BEFORE OPERATING

Your slatted pool cover is a **mechanical system**.

Correct operation and water conditions are **critical** to ensure smooth operation and prevent damage.

⚠ Failure to operate the cover correctly may cause jamming, fouling, or damage. Damage caused by incorrect operation, incorrect water level, debris, or misuse is not covered by warranty.

2. WATER LEVEL – CRITICAL REQUIREMENT

The pool water level must always be correct before operating the cover.

Correct water level:

- At or near the **middle of the skimmer opening** (or as advised at handover).
- Water must fully support the slats as they travel.

If the water level is too low:

- The cover can **drag, skew, jam or foul**
- Excess load is placed on the motor and mechanism
- Slats and tracks may be damaged
- **This damage is not covered by warranty**

⊘ Never operate the cover if the water level is low.

3. NORMAL OPERATION – HOW TO USE

✔ Always visually monitor the cover while it is moving.

When opening or closing:

- Stand where you can clearly see the full cover.
- Start the cover using the controller / key / switch.
- **Watch the cover at all times while it is moving.**
- The cover should move smoothly and evenly.

● STOP IMMEDIATELY if:

- The cover catches, lifts, twists, or looks uneven
- A slat jams or rides up
- The cover does not move in or out smoothly
- You hear unusual noises or straining

Do not force the cover.

Investigate the cause or contact Daisy Pool Covers before continuing

4. WHAT TO CHECK BEFORE EVERY USE

Before operating the cover, **always check:**

- ✔ Pool water level is correct
- ✔ No people, pets, or objects are in the pool
- ✔ No large debris (leaves, sticks, toys) on or in the path of the cover
- ✔ Tracks are clear and unobstructed
- ✔ Steps, ladders, or pool accessories are removed or in the correct position
- ✔ No heavy water load sitting on top of the cover

5. WHAT NOT TO DO (VERY IMPORTANT)

- ⊘ Do not operate the cover without watching it
- ⊘ Do not force the cover if it stops or jams
- ⊘ Do not allow children to operate the cover
- ⊘ Do not allow anyone to swim while the cover is moving
- ⊘ Do not walk or stand on the cover unless specifically rated for that purpose
- ⊘ Do not operate the cover with low water level
- ⊘ Do not leave the cover partially open
- ⊘ Do not place furniture, pot plants, or heavy objects on the cover
- ⊘ Do not allow debris to build up in tracks or cover housing

These actions commonly **void manufacturer warranties.**

6. DEBRIS & WATER ON THE COVER

- ✔ Regularly remove leaves and debris before opening or closing.
- ✔ Pump off standing water if required.

⚠ Excess water or debris increases load and can damage the system.

Damage caused by debris, standing water, or lack of maintenance is not covered by warranty.

7. CHEMICALS & WATER BALANCE

- ✓ Only close the cover on **balanced, swimmable water**.
- ✓ After adding chemicals:
 - Leave the cover open for **at least 1–2 hours**
 - Allow chemicals to circulate fully
- ✗ Do not use floating chlorine dispensers under a closed cover
- ✗ Do not close the cover immediately after shocking the pool

Chemical damage is not covered by warranty.

8. GENERAL MAINTENANCE CHECKS (OWNER RESPONSIBILITY)

Regularly check:

- Cover alignment and smooth travel
 - Area in and around roller clean and free of grit
 - No visible damage to slats or guides
 - Control Housing area is undercover, clean and dry
- ⚠ **Do not attempt mechanical adjustments yourself** unless instructed by Daisy Pool Covers or an authorised technician.

9. SAFETY NOTICE

- The pool cover is **not a substitute for supervision**.
- Never allow children to play on or operate the cover.
- Never swim while the cover is opening or closing.
- Never leave the cover partially open.

10. WARRANTY CLARIFICATION (IMPORTANT)

Your warranty **does not cover damage caused by:**

- Incorrect water level
- Forcing the cover
- Operating without supervision
- Debris, standing water, or chemical misuse
- Misuse or lack of maintenance
- Failure to follow this operation guide

11. WHEN TO CONTACT DAISY POOL COVERS

Contact us immediately if:

- The cover jams or fouls
- The cover does not travel evenly
- You notice unusual noises or resistance
- Slats lift, twist, or misalign
- You are unsure whether it is safe to operate

Do not continue operating the cover until assessed.

12. HANDOVER CONFIRMATION

- ✓ System demonstrated to owner
- ✓ Correct water level explained
- ✓ Safe operation explained
- ✓ Do's and Don't's explained
- ✓ Owner understands visual monitoring requirement

OWNER SIGNATURE

DATE

INSTALLER

DATE
